







Installationsanleitung VS Compact Beschaltungskonsole
Installation guide VS Compact Wiring Base
Instructions de montage VS Compact console de connexion



4



5



Headquarters

Switzerland

Reichle & De-Massari AG

Binzstrasse 32

CHE-8620 Wetzikon

Telephone HQ +41 (0)44 933 81 11

Telefax HQ +41 (0)44 930 49 41

E-Mail hq@rdm.com

www.rdm.com

R&M