














# Installationsanleitung Kleinverteilergehäuse IP54

## Installation guide small distributor box IP54


### Instructions de montage petit boîtier IP54









**Frontplatte mit 4 x RJ45 / front plate with 4 x RJ45**



# LWL Spleisskassette R30, R40 / FO splice tray R30, R40



## Headquarters

### Switzerland

Reichle & De-Massari AG

Binzstrasse 32

CHE-8620 Wetzikon

Telephone HQ +41 (0)44 933 81 11

Telefax HQ +41 (0)44 930 49 41

E-Mail [hq@rdm.com](mailto:hq@rdm.com)

[www.rdm.com](http://www.rdm.com)

