








Installationsanleitung Fasermanagement ODF SpleissMODUL (links & rechts)  
Installation guide Fiber guide ODF SpliceMODULE (left & right)  
Instructions de montage gestion des câbles ODF SpliceModule (gauche & droit)



021.2681



021.2684 / 021.2685



## Headquarters

### Switzerland

Reichle & De-Massari AG

Binzstrasse 32

CHE-8620 Wetzikon

Telephone HQ +41 (0)44 933 81 11

Telefax HQ +41 (0)44 930 49 41

E-Mail [hq@rdm.com](mailto:hq@rdm.com)

[www.rdm.com](http://www.rdm.com)

**R&M**