



Installation guide Netscale BCM Housing
Installationsanleitung Netscale BCM Gehäuse
Instructions de montage Netscale BCM Housing




021.4795

A - Scope of delivery







021.4781



B - Horizontal mount in 19" rack



C - Vertical mount in 19" rack (OPTIONAL)




D - Support Bar (OPTIONAL)




E - Optional Accessories

E1 Vertical Mount Kit




E2 Support Bar




E3 Small Size Divider Clip



E4 Mid Size Divider Clip



E5 Blind Modules



021.4812

Headquarters

Switzerland

Reichle & De-Massari AG

Binzstrasse 32

CHE-8620 Wetzikon

Telephone HQ +41 (0)44 933 81 11

Telefax HQ +41 (0)44 930 49 41

E-Mail hq@rdm.com

www.rdm.com

R&M

843716/A/10.2017